CAVITY-FG PRODUCT					
OPERATION PROCEDURE: 4-OP-378	Version: 67	Page: 1/54	4-OP-378/67		

# I. Purpose

This operation procedure is used for setting up the manufacturing processes for Cavity-FG product

Table II.1 Products general information 67 II. Application



	<b>11. Application</b> Table II.1 Products general information							<u>/67</u>	_					
FOV code	QC flow chart	Type name	Specification No.	RV	RLS (mm)	MCS	D.S	FV	PT	IP	OP	Spectrum type	Thermal aging (heating after exposing)	Apply hot air at stripping process
CFS0002	4-QC-378	DXV	AOP82-4001-27-04	RV1	30~55	Red	D01	FV1	В	Patt 2	Patt A	Uniform	Cartridge	Yes
CFS0006	4-QC-378	DUV	AOP82-4001-27-04	RV1	30~55	Red	D01	FV1	В	Patt 2	Patt A	Uniform	Cartridge	Yes
CFS0054	4-QC-378	HCV	AOP82-4001-27-11	RV3	>25	No	D06	FV2	G	Patt 7	Patt C	Chirped	Hot air	No
CFS0059	4-QC-378	YUV	AOP82-4001-27-04	RV1	30~55	Red	D01	FV1	Е	Patt 5	Patt B	Uniform	Cartridge	Yes
CFS0063	4-QC-378	WAV	AOP82-4001-27-10	RV2	<50	No	D03	FV2	С	Patt 3	Patt B	Uniform	No	No
CFS0064	4-QC-378	YXV	AOP82-4001-27-04	RV1	30~55	Red	D01	FV1	Е	Patt 5	Patt B	Uniform	Cartridge	Yes
CFS0066	4-QC-0154	NAV	AOP81-2122-27-01	RV1	30~55	Black	D02	FV1	A	Patt 1	Patt A	Uniform	Cartridge	No
CFS0067	4-QC-0154	NBV	AOP81-2122-27-01	RV1	30~55	Black	D02	FV1	A	Patt 1	Patt A	Uniform	Cartridge	No
CFS0068	4-QC-0154	NCV	AOP81-2122-27-01	RV1	30~55	Black	D02	FV1	A	Patt 1	Patt A	Uniform	Cartridge	No
CFS0069	4-QC-0154	NWV	AOP81-2122-27-01	RV1	30~55	Red	D07	FV1	F	Patt 6	Patt C	Uniform	Cartridge	No
CFS0070	4-QC-0154	NUV	AOP81-2122-27-01	RV1	30~55	Red	D07	FV1	F	Patt 6	Patt C	Uniform	Cartridge	No
CFS0071	4-QC-378	KEV	AOP82-4001-27-09	RV2	<50	Red	D05	FV2	D	Patt 4	Patt B	Chirped	No	Yes
CFS0073	4-QC-378	KDV	AOP82-4001-27-09	RV2	<50	Red	D05	FV2	D	Patt 4	Patt B	Chirped	No	Yes
CFS0074	4-QC-378	HDV	AOP82-4001-27-11	RV3	>5	No	D06	FV2	G	Patt 7	Patt C	Chirped	Hot air	No
CFS0075	4-QC-378	KCV	AOP82-4001-27-09	RV2	<50	Red	D05	FV2	D	Patt 4	Patt B	Chirped	No	Yes
CFS0077	4-QC-378	WBV	AOP82-4001-27-10	RV2	<50	No	D03	FV2	С	Patt 3	Patt B	Uniform	No	No
CFS0078	4-QC-378	YAV	AOP82-4001-27-04	RV1	30~55	Red	D01	FV1	Е	Patt 5	Patt B	Uniform	Cartridge	Yes
CFS0079	4-QC-378	YEV	AOP82-4001-27-04	RV1	30~55	Red	D01	FV1	Е	Patt 5	Patt B	Uniform	Cartridge	Yes
CFS0080	4-QC-378	YDV	AOP82-4001-27-04	RV1	30~55	Red	D01	FV1	Е	Patt 5	Patt B	Uniform	Cartridge	Yes
CFS0081	4-QC-0154	NXV	AOP81-2122-27-01	RV1	30~55	Red	D07	FV1	F	Patt 6	Patt C	Uniform	Cartridge	No
CFS0082	4-QC-0154	NYV	AOP81-2122-27-01	RV1	30~55	Red	D07	FV1	F	Patt 6	Patt C	Uniform	Cartridge	No
CFS0087	4-QC-0154	NDV	AOP81-2122-27-01	RV1	30~55	Black	D02	FV1	A	Patt 1	Patt A	Uniform	Cartridge	No
CFS0089	4-QC-378	HEV	AOP82-4001-27-11	RV3	>5	No	D06	FV2	G	Patt 7	Patt C	Uniform	Hot air	No
CFS0090	4-QC-378	KBV	AOP82-4001-27-09	RV2	<50	Red	D05	FV2	D	Patt 4	Patt B	Chirped	No	Yes
CFS0091	4-QC-378	SAV	AOP82-4001-27-14	RV1	30~55	Red	D01	FV1	В	Patt 2	Patt A	Uniform	Cartridge	No
CFS0092	4-QC-378	SCV	AOP82-4001-27-14	RV1	30~55	Red	D08	FV1	В	Patt 2	Patt A	Uniform	Cartridge	No
CFS0093	4-QC-378	CAV	AOP82-4001-27-13	RV1	<50	No	D09	FV1	Н	Patt 8	Patt B	Uniform	No	Yes
CFS0097	4-QC-378	XCV	AOP82-4001-27-10	RV2	<50	No	D03	FV2	С	Patt 3	Patt B	Uniform	Cartridge	No
CFS0098	4-QC-378	XDV	AOP82-4001-27-10	RV2	<50	No	D03	FV2	С	Patt 3	Patt B	Uniform	Cartridge	No
CFS0099	4-QC-378	PAV	AOP82-4001-27-10	RV2	<50	Red	D05	FV2	D	Patt.4	Patt B	Chirped	No	No
CFS0100	4-QC-378	HHV	AOP82-4001-27-11	RV3	>5	No	D06	FV2	G	Patt 7	Patt C	Uniform	Hot air	No
CFS0103	4-QC-378	TAV	AOP82-4001-27-15	RV1	40~50	Red Black	D10	FV1	J	Patt 9	Patt B	Uniform	Cartridge	Yes
CFS0104	4-QC-378	TBV	AOP82-4001-27-15	RV1	40~50	Red Black	D10	FV1	J	Patt 9	Patt B	Uniform	Cartridge	Yes
CFS0105	4-QC-378	UAV	AOP82-4001-27-16	RV1	<55	Red Black	D11	FV1	J	Patt 9	Patt B	Chirped	Cartridge	No
														<u> </u>

Approved by: Dao Ngoc Trung Date: (Follow DMS)	Approved by: Department/Division Manager Date: (Follow DMS)
Prepared by: VietTA - Cross Check by: ChienPH Date: 14-Aug-2024	Originator: Le Minh Duy Date: 26-Jun-2013

Confidential FOV 's property, do not take out without FOV BOM's approval

CAVITY-FG PRODUCT					
OPERATION PROCEDURE: 4-OP-378	Version: 67	Page: 2/54			

CFS0106	4-QC-378	UBV	AOP82-4001-27-16	RV1	<55	Red Black	D11	FV1	J	Patt 9	Patt B	Chirped	Cartridge	No
CFS0115	4-QC-378	XFV	AOP82-4001-27-10	RV2	<50	No	D03	FV2	С	Patt 3	Patt B	Uniform	Cartridge	No
CFS0116	4-QC-378	XEV	AOP82-4001-27-10	RV2	<50	No	D03	FV2	C	Patt 3	Patt B	Uniform	Cartridge	No
#NA	4-QC-378	HKV	AOP82-4001-27-11	RV3	>5	No	D06	FV2	G	Patt 7	Patt C	N/A	Hot air	No
#NA	4-QC-378	HJV	AOP82-4001-27-11	RV3	>5	No	D06	FV2	G	Patt 7	Patt C	N/A	Hot air	No
#NA	4-QC-378	HFV	AOP82-4001-27-11	RV3	>5	No	D06	FV2	G	Patt 7	Patt C	N/A	Hot air	No
#NA	4-QC-378	HGV	AOP82-4001-27-11	RV3	>5	No	D06	FV2	G	Patt 7	Patt C	N/A	Hot air	No
#NA	4-QC-378	SBV	AOP82-4001-27-14	RV1	30~55	Red	D08	FV1	В	Patt 2	Patt A	N/A	Cartridge	No

# Noted:

D.S: Dimension specification

FV: Visual inspection criteria of Fiber section. RV: Visual inspection criteria of Recoat section.

IP: Inner Packing. OP: Outer Packing.

RLS: Recoating length specification. MCS: Marking color specification.

PT: Packing type

#NA: Will be define when PLN require

The content of operation procedure is applied to Cavity-FG products manufactured in Fujikura Fiber Optics Vietnam Ltd

### **Including following processes:**

Table II.2 Processes for Cavity-FG 67



No.	Process
1	Material preparation
2	Fiber Rewinding
3	Hydrogen Loading
4	Fiber Cutting
5	Fiber Stripping
6	Exposing & Thermal Aging
7	Thermal Aging (hot air)
8	Recoating
9	Marking and Proof test
10	Hydrogen Unloading
11	Visual Inspection (Recoat)
12	Optical measurement
13	Visual Inspection and Packing
14	Final Packing
15	Test report & Shipping

This procedure directly to Production (PRD), Production Engineering (PRE), Quality Assurance Engineering (QAE) and Planning (PLN).

CAVITY-FG PRODUCT					
OPERATION PROCEDURE: 4-OP-378	Version: 67	Page: 3/54			

# **III. Reference Documents:**



# 1. Specification No.:

No	Specification	Name
1	AOP82-4001-27-04(18)	Cavity-FG (SM980 for Lumentum)
2	AOP82-4001-27-09(21)	Cavity-FG (SM980 for Coherent)
3	AOP82-4001-27-11(17)	Cavity-FG (80µm PM980 for Coherent)
4	AOP82-4001-27-10(17)	Cavity-FG (PM980 for Coherent)
5	AOP81-2122-27-01(19)	Cavity-FG (PM980 for Submarine)
6	AOP82-4001-27-13(05)	Cavity-FG (SM980 for Dogain Tech)
7	AOP82-4001-27-14(05)	Cavity-FG (PM980 for Lumentum)
8	AOP82-4001-27-06(14)	Manufacturing condition of Cavity-FG
9	AOP82-4001-27-07(9)	Requirement for quality assurance of Cavity-FG
10	AOP82-4001-27-08(24)	Packing requirement of Cavity-FG
11	AOP82-4001-27-05(26)	Visual inspection of Cavity-FG
12	AOP81-2122-27-02(02)	Requirement for Submarine Cavity-FG manufacturing
13	AOP82-4001-27-12(04)	Requirement for Deliverable data and Environmental information of Cavity-FG
14	AOP82-4001-27-15(03)	Cavity-FG (SM980 for 3SP)
15	AOP82-4001-27-16(03)	Cavity-FG (PM980 for 3SP)

# 2. Working Direction No.:

N	lo	Working direction	Name	<b>Application process</b>
	1	PTE82-59-21-2010	Working direction about visual inspection for Submarine products	Recoat Inspection & Fiber Inspection

# IV. Term definition:

- FG: Fiber Grating

- Recoat: a layer of acrylate material

CAVITY-FG PRODUCT				
OPERATION PROCEDURE: 4-OP-378	Version: 67	Page: 4/54		

# V. ROHS material requirement & Traceability control:

1. <u>ROHS</u> material <u>requirement</u>

Table V.1 List of material required RoHS compliance.

Item	Material name	Description			
1	Ontical Fibor	Corning-HI1060, Fujikura-SM98PSU25DH, Fujikura-RCSM98PSU17C,			
1	Optical Fiber	Fujikura-RCSM98PSU17D, Fujikura-HASM1060			
2	Recoat resin 950-200 (Desolite) or 950Y200(JFC)				
3	Moulting man	Artline K-50 Red (Shachihata), Artline K-50 Black (Shachihata)			
3	Marking pen	Artline EK-50 Red (Shachihata), Artline EK-50 Black (Shachihata)			
4	Packing case	Packing Case for Cavity FG ver.2*, Antistatic Packing Case (60pcs Cavity-			
	-	FG)			
5	Reel Lite	SPOOL-1-ST (OPTO QUEST)*			
6	Individual label	TZe-221 (Brother)			
7	Packing label	TZe-251 (Brother)			
8	Individual label	TZe-231 (Brother)			
9	Zipper bag	GP-F-4-YOKONAGA (SEISANNIPPONSHA) or equivalent material (i)			
10	Silicone spiral tube	KEPSi-2-3 (HAGITEC) or equivalent material (i)			
11	Fushigi tape (white)	Fushigi tape (Nirei industory)			
12	Mending tape	Magic Tape (Scotch)			

<sup>(</sup>i) Need to use material approved by FJK.

# 2. Traceability control:

Type of Record	Items	Record
Quality control items	Refer to 4-QC-378 or 4-QC-0154	
Identification and traceability record	- Material Lot#	
	- Operation date	Manufacturing program
	- Machine/Tool-jig control number	/Checksheet
	- Operator code	
	- Manufacturing/ inspecting date	

# **VI. Content:**

# 1. Incoming Inspection

Item	Specification
Length of spiral tube	5 ~ 10mm
Length of scotch tape	~ 90mm
Length of the fold	~ 5mm
Length and quantity of	+ ~ 550 x 160mm, 1 sheet
air bubble sheet for an	$+ \sim 450 \text{ x } 200 \text{mm}, 1 \text{ sheet}$
inner carton box	+ ~190 x 130mm, 9 sheets
	+ Aluminum board and silicon gum's groove must be not dirty,
	damaged
Annegrance	+ Spiral tube & Scotch tape: Not dirty (contamination), both of
Appearance	end must be straight, not deviated
	+ Air bubble: Edges must be straight, not deviated
	+ Packing case/bag must not be dirty, damaged

CAVITY-FG PRODUCT				
OPERATION PROCEDURE: 4-OP-378	Version: 67	Page: 5/54		

# 1.2 Process condition

Item	Condition
Appearance	Visual
Length of spiral tube	Jig/Ruler
Length of scotch tape	Machine
Length of the fold	Visual
Quantity of air bubble	Counting and visual

# 2. Fiber Rewinding

# 2.1 Process specification

Item	Specification
	- Rewinding length of fiber is 250 m/reel
Fiber rewinding length	- In case of end of bobbin, the rewinding length can be over 250m
	but less than 300m.
Appearance	- Fiber layer should not over the border of reel (See Fg 2.1.2).
Appearance	- There is no damage or deformation of fiber and reel.



Fg 2.1.1: Optical Fiber Rewinding Machine



Blue reel for SM98-PS-U25D-H Fujikura




White reel for SMHI1060 Coming



Yellow reel for RCSM98-PS-U17C-H



Red reel for RCSM98-PS-U 17D-H



Fiber layer should not over the border of reel

The border of reel

Fiber layer

# Fg 2.1.2: Optical Fiber Reel (aluminum)

# 2.2 Process condition

Item	Condition
Fiber rewinding length	Machine setting (See Fg 2.1.1).
Appearance	Visual

CAVITY-FG PRODUCT				
OPERATION PROCEDURE: 4-OP-378	Version: 67	Page: 6/54		


# 3. Hydrogen Loading

Item	Specification
Loading pressure	Pressure is 9.0 ~ 11.0 Mpa
Loading temperature	Temperature is less than 70°C (Optimal condition: 55 ~ 65°C)
Loading time	Loading time is equal or greater than 24hrs.
Pot life of fiber (or Storage time)	* Storage at room temperature (Storage time @RT):  - Pot life should: ≤ 8hr  * Storage time at low temperature:  - Fiber must be used less than 24 hours (Optimal condition: 22hours)  - Storage temperature: -40°C < T < -20°C (Setting value)  - Reel package: should be packaged individually in a zipper bag




Fg 3.1.1: Hydrogen Loading Chamber





Fg 3.1.2: Putting Optical Fiber Reel (aluminum) into Chamber







Fg 3.1.4: Temperature of Hydrogen Loading



Fg 3.1.5: Packing reel before put into low-temperature storage

Confidential FOV 's property, do not take out without FOV BOM's approval

CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378	Version: 67	Page: 7/54	

# 3.2 Process condition

Item	Condition		
Pot life of fiber	Visual (expiration date on reel)		
Pressure	Hydrogen looding machine		
Temperature	Hydrogen loading machine		
Loading time	Clock, Checksheet		
Storage time	- Clock, Checksheet		
Storage time	- Visual (expiration date on reel)		
Storage at low temperature	Freezer or equivalent equipment		

# 4. Fiber cutting

Item	Specification
Pot life of fiber	Fiber must be used less than 24 hours after taking out Hydrogen loading chamber. (Optimal condition: 22hours)
Cutting length	Prefer to table 4.1.1
Yellow port position (yellow tape)	Prefer to table 4.1.1 and Figure 4.1.1
Red port position (red plastic tape)	Prefer to table 4.1.1 and Figure 4.1.1

Table 4.	Table 4.1.1 Cutting length of Cavity-FG. 67				
Group	Type name	L1	L2	L3	Total length of cutting (mm)
1	DUV, DXV, DYV, YDV, YEV, YUV, YXV	$830 \pm 50$	$820 \pm 50$	$1100 \pm 50$	~ 2750
2	NAV, NBV	$860 \pm 50$	$820 \pm 50$	$2530 \pm 50$	~ 4210
3	WAV	$660 \pm 50$	$820 \pm 50$	$2010 \pm 50$	~ 3490
4	XAV	$660 \pm 50$	$820 \pm 50$	$1260 \pm 50$	~ 2740
5	XBV, WBV	$660 \pm 50$	$820 \pm 50$	$510 \pm 50$	~ 1990
6	KBV, KCV, KYV, KXV	$1505 \pm 50$	$820 \pm 50$	$665 \pm 50$	~ 2990
7	HCV, HDV, HEV, HFV, HGV, HHV,HJV,HKV	N/A	$640 \pm 20$	$945 \pm 20$	~ 1735
8	KDV, KEV	$460 \pm 50$	$820 \pm 50$	$760 \pm 50$	~ 2040
9	YAV	$1580 \pm 50$	$820 \pm 50$	$1100 \pm 50$	~ 3500
10	NCV, NDV	$1480 \pm 50$	$820 \pm 50$	$2550 \pm 50$	~ 4850
11	NYV, NXV	$1425 \pm 50$	$820 \pm 50$	$2745 \pm 50$	~ 4990
12	XCV, XDV	$1950 \pm 50$	$820 \pm 50$	$1270 \pm 50$	~ 4040
13	NWV, NUV	$765 \pm 50$	$820 \pm 50$	$2745 \pm 50$	~ 4330
14	SAV	$835 \pm 50$	$820 \pm 50$	$1375 \pm 50$	~3030
15	SBV, SCV	$1615 \pm 50$	$820 \pm 50$	$1095 \pm 50$	~3530
16	CAV	$865 \pm 50$	$820 \pm 50$	$1095 \pm 50$	~2780
17	PAV	$455 \pm 50$	$820 \pm 50$	$725 \pm 50$	~2000
18	UAV, UBV	$1085 \pm 50$	$820 \pm 50$	615± 50	~2520
19	TAV, TBV	$1845 \pm 50$	$820 \pm 50$	$1075 \pm 50$	~3740
20	XEV, XFV	$2755 \pm 50$	$820 \pm 50$	$2815 \pm 50$	~6390

CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378	Version: 67	Page: 8/54	




Figure 4.1.1 Diagram of cutting length - Cavity-FG




Figure 4.1.2 Diagram of cutting length - Cavity-FG (PM80um group)

# 4.2 Process condition

Item	Condition
Pot life of fiber	Program
Length of cutting	Jig
Position of starting winding fiber: Yellow port	Visual, Jig
Position of starting winding fiber: Red port	Visual, Jig
Fiber Type	Visual reel color

# 5. Fiber stripping

Item	Specification
	- Checking bare fiber appearance by microscope. (Fg 5.1.8)
Appearance	- There are not: contamination on the glass at the middle area, contamination burned
checking	changing brown or black, peeling off the edge of primary coat, stripping sharp.
microscope	- Stripping shape for Corning fiber and 80 um fiber as the Fg 5.1.3
	- Stripping shape for Fujikura fiber as the Fg 5.1.4.
	At the middle of INPUT PORT (Yellow port) and OUTPUT PORT (Red port).
Position of stripping   Note: For PM80um group, position of stripping at the middle of the end fiber left	
	port and the end of the red tape port's fiber wrap (Fg 5.1.2)
Cleaning bare fiber	- Cleaning bare fiber by acetone right after stripping. (Fg 5.1.7)
- Not touched bare fiber by anything.	
	Daily check, 1 sample.
- Fiber 80um: < 4.5 mm	
Stripping length	- Other fiber: 20 ~ 30mm
	- Dogain Tech (CAV type): 8 ~ 12mm
Apply hot air (*)	- Hot air temperature < 650°C

### **CAVITY-FG PRODUCT**

OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 9/54

- Hot air strip movement: 18mm (other SM types), 7mm (CAV type)
- UV remain: < 2mm from stripping end (Fg 5.1.6)


(\*) Refer to table II.1, "Apply hot air at stripping process" column




Fg 5.1.1: Stripping by CO2 Laser machine



<u>Fg 5.1.2:</u> Check balance of fiber before setting to machine (apply for PM80um group)




<u>Fg 5.1.3:</u> Stripping shape for Corning fiber and 80um fiber



Fg 5.1.4: Stripping shape for Fujikura fiber



<u>Fg 5.1.5:</u> Stripping by hot air machine (SM980)



<u>Fg 5.1.6:</u> UV remain < 2mm from stripping end  $\rightarrow$  OK



Fg 5.1.7: Cleaning bare fiber by acetone and ultrasonic machine



<u>Fg 5.1.8:</u> Checking bare fiber by microscope.



<u>Fg 5.1.9:</u> Fiber stripping, setting and winding fiber on metal board. Yellow port is left and red port is right.

### 5.2 Process condition

Item	Condition	Remark
WIP control	Visual (Optimum condition: 5pcs)	For good yield% at Exposing, - The WIP should be controlled not over 5pcs normally to keep input to Exposing within 2 hours after cutting If process stopped for any reason, Leader up

CAVITY-FG PRODUCT		
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 10/54		

		must re-confirm WIP before input as following: + If don't use refrigerator: Don't excessed 8hours after taking out from Hydro Loading chamber. + If use refrigerator: Don't excessed 8 hours after taking out from refrigerator and don't excessed 24h after taking out from Hydro Loading chamber.
Appearance of bare fiber	Visual by microscope	
Position of stripping	Visual	
Equipment control: + Stripping length + Proof test	Ruler (Daily checking) Proof tester (Daily checking)	
Stripping condition control	Daily Pull test (Breaking test)	Check the breaking strength before mass production usage: - Frequency: 3pcs/condition/ machine/shift - Breaking force: + ≥ 5 kg.f, 1 sec for 125um fiber + ≥ 2 kg.f, 1 sec for 80um fiber
	Reliability test or verification	Refer to 4-PR-006 for detail requirement
Operator skill control	Pull test (Breaking test)	Refer to 4-PR-006 for detail requirement
Hot air temperature	Visual (Machine setting)	Refer to table II.1, "Apply hot air at stripping process" column.
Hot air strip movement	Machine setting	Refer to table II.1, "Apply hot air at stripping process" column.

# 6. Exposing and Thermal aging

Noted: Thermal aging has been applies base on requirement of product code (see the Table II. 1 Products general information).




Item	Specification
Exposing result	
Center wavelength	
Reflectivity	Control oritorio by ontical massymment result
Full Width Half Max	Control criteria by optical measurement result
Side Lobe Suppression Ratio	
Spectrum type	
Excimer Laser Energy	Manufacturing: 120mJ, mode EGY-N or EGY-P, 40Hz
Excimer Laser Density	< 3 mJ/mm <sup>2</sup> (weekly checking)
Heater Temperature	>380°C
Aging Time	$15 \pm 2$ seconds (Setting time on program)






Confidential FOV 's property, do not take out without FOV BOM's approval


CAVITY-FG PRODUCT		
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 11/54		



Fg 6.1.2: Thermal Aging



Fg 6.1.3: Exposing system of Cavity FG



Fg 6.1.4: Exposing program


CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 12/54			

# 6.2 Process condition

Item	Condition	Remark
WIP control	Visual (Optimum condition: 10pcs)	For good yield% at Exposing, - The WIP should be controlled not over 10pcs normally to keep input to Exposing within 2 hours after cutting If process stopped for any reason, Leader up must re-confirm WIP was not excessed 24hours after Hydrogen loading before input.
Position of bare fiber FBG (80um)	Template	
<b>Equipment control:</b>		
+ Excimer Laser Energy	+ Excimer laser machine (Daily	
	checking)	
+ Excimer Laser Density	+ Laser power meter, ruler,	
	calculation (Weekly checking)	
+ Heater Temperature	+ Exposing system (and program)	
	(Daily checking)	
+ Heating Time	+ Exposing system (and program)	
	(Daily checking)	
Exposing result:		
+ Center wavelength		
+ Reflectivity	Manufacturing program, measuring	
+ Full Width Half Max	system	
+ Side Lobe Suppression	Visual by checking OSA	
Ratio		
+ Spectrum type		

# 7. Thermal Aging (hot air) process

Item	Specification
Hot air temperature	>500°C
Stripping movement	2.5 mm
Pre-Heating	10 sec
Velocity	3.0mm/sec
Appearance	Check length of deformation or discoloration of fiber coating is less than 0.25mm (Fg 7.1.1) - Frequency: 3pcs/OP/day
Magnification	40X



Fg. 7.1.1: Heating Area criteria at hot air


CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 13/54			

# 7.2 Process condition

Item	Condition
Hot Air Temperature	Machine Setting
Appearance	Microscope

# 8. Recoating process

Item	Specification
Appearance	Coating zone must not be over heat (change color), white, dried.  Peel off: prefer to section 11. Visual inspection (recoating zone).
	Dent: prefer to section 11. Visual inspection (recoating zone).  Dirty (contamination): prefer to section 11. Visual inspection (recoating zone).
Shape of UV resin on mold after recoating	After recoating, shape of UV resin on mold must be rhombus (see 8.1.5) but not apply for D06.
Recoating mold diameter sample.	D01, D02,D07, D08,D09,D10,D11: $300 \pm 30$ µm. Refer to table II.1, DS column. D03, D05: $\leq 320$ µm. Refer to table II.1, DS column. D06: $< 260$ µm. Refer to table II.1, DS column.
Cleaning's recoating	- Cleaning's liquid: clean alcohol (F.g 8.1.4) - Cleaning in 3~5 second.



Fg 8.1.1: Mold cleaning



Fg 8.1.2: Adhesive injection and curing



Fg 8.1.4: Cleaning by Alcohol
Contidential FOV's property, do not take out v



Fg 8.1.3: Remove from mold



<u>Fg 8.1.5:</u> The shape of UV resin on mold must be rhombus after recoating

CAVITY-FG PRODUCT				
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 14/54				

# 8.2 Process condition

Item	Condition	
Appearance	Visual by microscope	
<b>Equipment control:</b>		
+ Recoating diameter	Microscope (Daily checking)	
+ Appearance	Microscope (Checking sample)	
+ Recoating length	By template (Daily checking)	
Shape of UV resin on mold after recoating	Visual	
Recoat and UV curing	Recoater	
Remove burr/cleaning	Ultrasonic machine	


# 9. Marking and proof test:

# 9.1 Process specification

Note: The marking process will be apply for product, which defined detail in table


Item	Specification
	$+ \ge 1.8 \text{ kgf}$ , 1sec (NAV,NBV,NCV,NDV,NYV,NXV,NWV,NUV type)
Proof test level	$+ \ge 1.5$ kgf, 1sec (others product)
	$+ \ge 0.6 \text{ kgf}, 1 \text{sec } (80 \text{um } 980 \text{PM})$
Fiber pull strain rate	< 0.4mm/sec
Marking position	Mark must be located in marking area (Refer to F.g 9.1.1, 9.1.2 and 9.1.4)
+ 5~10mm (D05, D07: Refer to table II. 1, column D.S)	
Marking length	+ 5~20mm (D01, D02, D08: Refer to table II. 1, column D.S)
	+ 3~7mm (D10, D11: Refer to table II. 1, column D.S)
	+>5mm (D06: Refer to table II. 1, column RLS)
	+ 30mm~55mm (D01, D02, D07, D08, D11: Refer to table II. 1, column
Recoating length	RLS)
	+ 40~50mm (D10: Refer to table II. 1, column RLS)
	+ < 50mm (others product)
Color of marking	Refer to table II.1, MCS column.

# (D01)




CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 15/54			

(D02)



Fg 9.1.2: Products with black marking


(D03)



Fg 9.1.3: Products with no marking D03


\*No marking

(D05)



Fg 9.1.4: Products with two red marking on the right


(D06)



Fg 9.1.5: Products with no marking (fiber 80µm)


CAVITY-FG PRODUCT				
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 16/54				

(D07)




Fg 9.1.6: Products with red marking (NWV, NUV, NXV, NYV)

(D08)




Fg 9.1.7: Products with red marking (SBV, SCV)

(D09)



Fg 9.1.8 Products with no marking (CAV)


(D10)



Fg 9.1.9 Products with Red & Black marking (TAV & TBV)

CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 17/54			

(D11)




Fg 9.1.10 Products with Red & Black marking (UAV & UBV)




Fg 9.1.11: Proof test by machine





Fg 9.1.12: Marking by template



Fg 9.1.13: Marking by template for SBV, SCV

CAVITY-FG PRODUCT				
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 18/54				

# 9.2 Process condition

Item	Condition	
Appearance	Visual	
Proof test level	Proof tester (see Fg 9.1.11)	
Marking position		
Marking length	Template	
Recoating length		
Color of marking	Art-line pen	

# 10. Hydrogen Unloading

# 10.1 Process specification

Item	Specification
Temperature	+ 120°C ± 5°C Noted: Allowed temperature over 125°C but less than 130°C within first hour from when temperature goes up 115°C.
Unloading Time	+11.5~13 hours (690~ 780 min)




Fig 10.1: Unloading diagram

### 10.2 Process condition

Item	Condition	
Unloading Temperature Unloading Time	Oven & Thermal recorder	

# 11. Visual inspection (Recoating zone)

- 11.1 Process specification (Refer to table II.1, column RV)
  - + Recoat region should be continuous
  - + The recoat region must be fully cured and not tacky to the touch.
  - + Within the critical recoat zone, recoat must be continuous around the fiber circumference with no exposed glass or original acrylate coating

CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 19/54			

# 11.1.1 Apply for all products belong RV1

Item	Specification
	- Table 11.1.1.1: Defect Size and Frequency Criteria within Critical Recoat Zone
Appearance	- Table 11.1.1.2: Defect Size and Frequency Criteria
	within Outside Critical Recoat Zone




Table 11.1.1.1: Defect Size and Frequency Criteria within Critical Recoat Zone (RV1)

Defect Type	Defect Size/Condition	Acceptance level	Instrument and Method
Crack	Any	Not accept	Microscope: Magnification x40
Voids, Bubbles,	Maximum depth ≤ 30μm	Accept	
contamination, Dent	Max. dimension ≤ 30μm	Accept	
	Maximum dimension or depth or height ≤ 30μm, Max: 3 pcs	Accept	
Surface irregularities (not overlapped)	Maximum dimension or depth or height > 30μm	Not accept	
	Exposing original buffer coating	Not accept	
Recoat diameter (wo flash)	D01, D02, D07, D08, D09, D10, D11 <=270um or >= 330um	Not accept	
Recoat diameter (including flash)	D01, D02, D07, D08, D09, ≥ 350um D10, D11 >= 330um	Not accept	Microscope: inspect by Magnification x40 and measure by
Discoloration (From marking ink)	Easy to find by naked eyes	Not accept	Magnification x40
Brown ring	At buffer/glass interface	Not accept	
Discoloration (yellowing)	Dark yellow	Not accept	
Delamination	A bright reflection between the glass and the recoating layer >1mm	Not accept	


CAVITY-FG PRODUCT				
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 20/54				

Table 11.1.1.2: Defect Size and Frequency Criteria within Outside Critical Recoat Zone RV1

Defect Type	Defect Size/Condition	Acceptance level	Instrument and Method
Crack	Any	Not accept	
Contaminations	Sticking out from recoat surface	Not accept	
Voids, Bubbles, Dent	Any	Accept	
Surface irregularities (not overlapped)	Not expose original buffer coating over 3mm	Not accept	
Recoat diameter (wo flash)	D01, D02, D07, D08, D09 <= 270um or >= 330um	Not accept	Microscope: inspect by Magnification x40 and
Recoat diameter (including flash)	D01, D02, D07, D08, D09 ≥ 350um D10, D11 >= 330um	Not accept	measure by Magnification x40
Discoloration (From marking ink)	Easy to find by naked eyes	Not accept	
Brown ring	At buffer/glass interface	Not accept	
Discoloration (yellowing)	Dark yellow	Not accept	
Delamination	A bright reflection between the buffer coating (original) and the recoating layer is more than 3 mm from the end of recoating (both side)	Not accept	Microscope: inspect by Magnification x40 and measure by Magnification x20

# 11.1.2 Apply for all products belong RV2

Item	Specification	
Appearance	<ul> <li>Table 11.1.2.1: Defect Size and Frequency Criteria within Critical Recoat Zone</li> <li>Table 11.1.2.2: Defect Size and Frequency Criteria within Outside Critical Recoat Zone</li> </ul>	



CAVITY-FG PRODUCT				
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 21/54				

Table 11.1.2.1 Defect Size and Frequency Criteria within Critical Recoat Zone (RV2)

<b>Defect Type</b>	Defect Size/Condition	Acceptance level	Instrument and Method
Crack	Any	Not accept	
	Maximum depth > 30μm Max. dimension > 30μm	Not accept	
Contamination	Max. dimension ≤ 30μm Max: 3 pcs	Accept	
Voids Pubbles	Maximum depth > 30μm Max. dimension > 30μm	Not accept	
Voids, Bubbles	Max. dimension ≤ 30μm Max: 3 pcs	Accept	
Dent	Maximum depth > 30μm Exposing original buffer coating	Not accept	Microscope: inspect by Magnification x40
Recoat diameter	(D03, D05) > 320um	Not accept	and measure by  Magnification x40
Brown ring	At buffer/glass interface	Not accept	Wagiiii Cation x40
Discoloration (yellowing)	Dark yellow	Not accept	
Delamination	A bright reflection between the glass and the recoating layer>1mm	Not accept	
Surface	Maximum dimension or depth or height $\leq 30\mu m$ , Max: 3 pcs	Accept	
irregularities (not overlapped)	Maximum dimension or depth or height $> 30\mu m$	Not accept	
(FF)	Exposing original buffer coating	Not accept	

Table 11.1.2.2 Defect Size and Frequency Criteria within Outside Critical Recoat Zone (RV2)

Defect Type	<b>Defect Size/Condition</b>	Acceptance level	Instrument and Method	
Crack	Any	Not accept		
Contamination	Sticking out from recoat surface	Not accept		
Bubbles, Voids	Any Void, Bubble	Accept	Microscope: inspect	
Recoat diameter	(D03, D05) > 320um	Not accept	by Magnification x40 and measure by Magnification x40	
Surface irregularities (not overlapped)	Not expose original buffer coating over 3mm.	Not accept		
Discoloration (yellowing)	Dark yellow	Not accept		
Delamination	A bright reflection between the glass and the recoating layer >3mm	Not accept	Microscope: inspect by Magnification x40 and measure by Magnification x20	

Note: D03, D04, D05: Refer to table II.1, column D.S

CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 22/54			

# 11.1.3. Apply for all products belong RV3:

Item	Specification
Appearance	- Table 11.1.3.1: Defect Size and Frequency Criteria within Recoat Zone






Table 11.1.3.1 Defect Size and Frequency Criteria within Recoat Zone (RV3)

Defect Type	<b>Defect Size/ Condition</b>	Acceptance level	Instrument and Method
Dent, air bubble, delamination, shrink back	<ul> <li>Can be seen bare glass</li> <li>Recoat resin does not overlap rounded corners of fiber coating even if only for a part</li> </ul>	Not accept	Microscope: inspect by Magnification x40 and measure by Magnification x40
Recoating diameter (include flash)	> 260µm	Not accept	Microscope: inspect by Magnification x40 and measure by Magnification x40
Length between recoat edge and stripping end at the output (red port)	> 0.5 mm	Not accept	Ruler in microscope with Magnification x40
Glass exposure at the recoat overlap	Bare glass can be seen	Not accept	Microscope: inspect by Magnification x40
Deformation, discoloration	At buffer/glass interface	Not accept	Microscope: inspect by Magnification x40



Fg 11.1.3.1: Glass exposure at the recoat overlap samples

CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 23/54			



Fg 11.1.3.2: Schematics of Glass exposure at the recoat overlap

Defect example of RV3

Discoloration

Criteria: At buffer/glass interface is NG



Fig. 11.1.3.3. Discoloration sample

Deformation

Criteria: At buffer/glass interface is NG




Fig. 11.1.3.4. Deformation sample

CAVITY-FG PRODUCT				
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 24/54				

# 11.2 Process condition

Item	Condition
Appearance	Microscope
Inspection method (procedure)	<ul> <li>Step 1: set and adjust product in horizontal direction to see burr line (molding line) clearly.</li> <li>Step 2: do burr removing along the recoating zone</li> <li>Step 3: measure &amp; check recoating diameter</li> <li>Step 4: check the appearance of recoat area (contamination, void, air bubble,)</li> <li>Step 5: rotate product (recoat area) next 180 degree and repeat step 4.</li> <li>Step 6. rotate product (recoat area) next 90 degree and repeat step 4.</li> <li>Step 7: rotate product (recoat area) next 180 degree and repeat step 4.</li> <li>Note: keep one direction of rotation under checking to complete all sides of recoating surface.</li> </ul>

# 12. Optical Measurement




# 12.1 Process specification

<u>Table 12.1.1:</u> Optical parameter for each product

		Туре	Specification
	Splice Loss	All product types	$-0.1$ dB $\sim 0.3$ dB
		YDV, NDV, NXV, SCV	975.7 ~ 976.3 nm
		YEV	976.7 ~ 977.3 nm
		DUV, YUV	973.9 ~ 974.5 nm
		DXV, DYV, YXV, YAV, SAV, SBV	973.3 ~ 973.9 nm
		NAV, NWV	973.5 ~ 974.5 nm
		NBV, NUV	975.5 ~ 976.5 nm
on		WAV, XAV, XBV, WBV	973.75 ~ 974.25 nm
rati	Center	XCV, TAV, XEV	973.45 ~ 973.95 nm
Optical measurement configuration	wavelength	XDV, TBV, XFV	975.45 ~ 975.95 nm
onf	wavelengui	KBV, KYV, KDV, PAV	973.25 ~ 973.75 nm
ıt c		KCV, KXV, KEV	975.25 ~ 975.75 nm
mei		HCV, HEV, HGV, HHV, HJV, HKV	973.7 ~ 974.6 nm
ure		HDV, HFV	975.7 ~ 976.6 nm
eası		NCV, NYV	973.2 ~ 973.8 nm
m		CAV	973.7 ~ 974.3 nm
ical		UAV	974.05 ~ 974.55 nm
)pt		UBV	975.55 ~ 976.05 nm
	Reflectivity	DUV, DFV, DXV, YDV, YEV, YUV, YXV, YAV, CAV,	1.8 ~ 2.4%
		SBV, SCV	
		DYV, NAV, NBV, NWV, NUV	3.5 ~ 4.5%
		NCV, NXV, NYV, NDV	1.7 ~ 2.3%
		HCV, HDV	3.5 ~ 5.2%
		WAV	1.5 ~ 2.5%
		XAV, XBV	4.0 ~ 5.0%

CAVITY-FG PRODUCT				
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 25/54				

	XCV, XDV, XEV,XFV	2.5 ~ 3.5%
	KBV, KCV, KYV, KXV, KDV, KEV, PAV, TAV, TBV	1.75 ~ 2.25%
	WBV	5.0 ~ 6.0%
	HEV, HFV, HGV, HHV,HJV,HKV	5.4 ~ 7.2%
	SAV	1.8 ~ 2.2%
	UAV, UBV	7.5 ~ 8.5%
Full Width Half Max	DUV, DFV, DXV, DYV, YDV, YEV, YUV, YXV, NAV, NBV, NWV, NUV, CAV, SAV	0.35 nm ~ 0.45 nm
	WAV, WBV	0.4 nm ~ 0.6 nm
	XAV, XBV	1.2 nm ~ 1.4 nm
	KBV, KCV, KYV, KXV, KDV, KEV	1.1 nm ~ 1.4 nm
	HAV, HBV, HCV, HDV, HGV, HKV	1.1 nm ~ 1.5 nm
	YAV, SBV, SCV	0.8 nm ~ 1.2 nm
	NCV, NDV, NYV, NXV	0.9 nm ~ 1.1 nm
	HEV, HFV, HHV, HJV	0.5 nm ~ 1.0 nm
	XCV, XDV, XEV, XFV	0.7 nm ~ 0.9 nm
	PAV	1.1nm ~ 1.4 nm
	TAV, TBV, UAV, UBV	0.55nm ~ 0.75 nm
Side Lobe	DUV, DFV, DXV, DYV, NAV, NBV, WAV, YDV, YEV,	
Suppression	YUV, YXV, YAV, NCV, NDV, NYV, NXV, NWV, NUV,	≤-10dB
Ratio	WBV, CAV, SAV, SBV, SCV, TAV, TBV, UAV, UBV	
	XAV, XBV, HEV, HFV, HGV, HHV, HJV, HKV	≤ -15dB
	KBV, KCV, KYV, KXV, KDV, HCV, HDV, KEV, XCV, XDV, PAV, XEV, XFV	≤ -20dB



Fg 12.1.1: Optical measurement configuration

# 12.2 Process condition


Item Condition		
Environment temperature Thermometer (Monitoring system)		
Thermometer position	Fixed position and near to the product are measuring	
Splice Loss	Manufacturing program, measuring system	

I CJIRCKI I IDEK OF ITES VIETVAM EID.				
CAVITY-FG PRODUCT				
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 26/54				
Optical Measurement result:				
+ Center wavelength + Reflectivity				
<ul><li>+ Full Width Half Max</li><li>+ Side Lobe Suppression Ratio</li></ul>				


# 13. Visual Inspection and Packing

a. Process specification (Refer to table II.1, column FV1, FV2)

### 13.1.1 Visual Inspection



Fg 13.1.1.1: Defect mode on fiber (FV1)



Fg 13.1.1.2: Defect mode on fiber (FV2)


Table 13.1.1.1 Fiber Defect Size and Frequency Criteria


Defect Type	Defect Size/Condition	Acceptance level	
Discoloration	Easy to find by naked eyes	Not accept	
Contamination	> 30µm Contacting the glass	Not accept	
Delamination	Easy to find by naked eyes	Not accept	
Fiber compression (criteria of FV1)	Minimum diameter < 220μm OR Depth >25μm	Not accept	
Fiber compression (criteria of FV1)	Length in longitudinal direction > 5mm	Not accept	
Fiber compression (criteria of FV2)	Fiber UV 245μm: minimum diameter < 220μm	Not accept	
Fiber compression (criteria of FV2)	Fiber UV 165μm: minimum diameter < 150μm	Not accept	
Acrylate damage without exposed glass	Crack on fiber coating	Not accept	
Actyrate damage without exposed glass	Scratch (easy to find by naked eyes)	Not accept	
Acrylate damage with exposed glass	Exposed glass	Not accept	

CAVITY-FG PRODUCT				
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 27/54				



Figure 13.1.1.3: Fiber delamination with crack sample →NG








Figure 13.1.1.5: Exposed glass sample

Figure 13.1.1.6: Damage (Scratch) sample




Figure 13.1.1.7: Compression with crack





Figure 13.1.1.8: Fiber compression with diameter (FV1)



<u>Figure 13.1.1.9</u>: Fiber compression with length in longitudinal direction < 5mm, diameter >= 220um  $\rightarrow$  OK (FV1)




Figure 13.1.1.10: Fiber compression with diameter (FV2)


Table 13.1.1.2 Length of Cavity product



Group	Type name	L1(mm)	L2(mm)	Remark
1	DDV, DEV, DFV, DUV, DXV,	1075 + 25	$1275 \pm 25$	
	DYV, YDV, YEV, YUV, YXV	$10/3 \pm 23$	$12/3 \pm 23$	
2	NAV, NBV	$1105 \pm 25$	$2705 \pm 25$	
3	WAV	$895 \pm 25$	$2195 \pm 25$	Refer to figure 13.1.1.11
4	XAV	$895 \pm 25$	$1445 \pm 25$	
5	JAV, JBV, JYV, JXV, XBV, WBV	$895 \pm 25$	$695 \pm 25$	
6	KBV, KCV, KYV, KXV	$1745 \pm 25$	$845 \pm 25$	

CAVITY-FG PRODUCT				
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 28/54				

7	HAV, HBV, HCV, HDV, HEV, HFV, HGV, HHV, HJV, HKV	$30 \pm 10$	>1050	Refer to figure 13.1.1.12
8	KDV, KEV	$695 \pm 25$	$945 \pm 25$	
9	YAV	$1825 \pm 25$	$1275 \pm 25$	
10	NCV, NDV	$1725 \pm 25$	$2725 \pm 25$	
11	NYV, NXV	$1670 \pm 20$	$2925 \pm 25$	
12	XCV, XDV	$2195 \pm 25$	$1445 \pm 25$	
13	NWV, NUV	$1005 \pm 25$	$2925 \pm 25$	
14	SAV	$1075 \pm 25$	$1555 \pm 25$	Refer to figure 13.1.1.11
15	SBV, SCV	$1855 \pm 25$	$1275 \pm 25$	
16	CAV	$1105 \pm 25$	$1275 \pm 25$	
17	PAV	$695 \pm 25$	$905 \pm 25$	
18	TAV, TBV	$2085 \pm 25$	$1255 \pm 25$	
19	UAV, UBV	$1325 \pm 25$	$800 \pm 20$	
20	XEV, XFV	$2995 \pm 25$	$2995 \pm 25$	



Fg 13.1.1.12: Length of fiber 80μm

Table 13.1.1.3 Marking specification of Cavity product

Note: The marking process will be applied for product, which defined detail in table II.1

Item	Specification	
Marking position	Mark must be located in marking area (following F.g 9.1.1, 9.1.2 and 9.1.4)	
	+ 5~10mm (D05, D07: Refer to table II. 1, column D.S)	
Marking length	+ 5~20mm (D01, D02, D08: Refer to table II. 1, column D.S)	
	+ 3~7mm (D10, D11: Refer to table II. 1, column D.S)	
Color of marking	Refer to table II.1, MCS column.	


# 13.1.2. Inner Packing

13.1.2.1 Inner Packing for patt 1




Step 1: Winding fiber to reel by machine from red side

CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 29/54			






Step 3: After rewinding and labeling, there is no protrusion of fiber from REEL LITE



Step 4: Put 22 products in packing tray and cover 3 empty reels lite fixed by fushigi tape

### 13.1.2.2 Inner Packing for patt 2




Step 1: Winding fiber to reel by machine from red side

Step 2: The serial label is taped at the end of fiber

CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378	Version: 67	Page: 30/54	



Step 3: After rewinding and labeling, there must be no protrusion of fiber out of REEL LITE




Step 4: Plastic tray packing


# 13.1.2.3 Inner Packing for patt 3




Step 1: Winding fiber to reel by machine from red side.




CAVITY-FG PRODUCT					
OPERATION PROCEDURE: 4-OP-378	OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 31/54				



Step 2: Attach transparent tape to fiber end and attach serial label on it



Step 3: Remove bundled fiber from winding jig




Step 4: Bundle each fiber end keeping off recoating area by spiral tubes




Step 5: Put the individual fiber bundle into zipper bag and close the zipper.

CAVITY-FG PRODUCT		
OPERATION PROCEDURE: 4-OP-378	Version: 67	Page: 32/54

### 13.1.2.4 Inner packing for patt 4



Step 1: Rewind to the winding jig from red side






Step 2: Attach transparent tape to fiber end and attach serial label on it label on it



Step 3: Remove bundled fiber from winding jig

CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 33/54			




Step 4: Bundle each fiber end keeping off recoating area by spiral tubes




Step 5: Put the individual fiber bundle into zipper bag and close the zipper

# 13.1.2.5. Inner packing for patt 5




Step 1: Rewind to the winding jig from red side




Step 2: Attach serial label to yellow end

CAVITY-FG PRODUCT		
OPERATION PROCEDURE: 4-OP-378	Version: 67	Page: 34/54



Step 3: Remove bundled fiber from winding jig




Step 4: Bundle each fiber end keeping off recoating area by spiral tubes



Step 5: Put the individual fiber bundle into zipper bag and close the zipper

# 13.1.2.6 Inner packing for patt 6




Step 1: Rewind to the winding jig from red side


CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 35/54			




Step 2: Attach serial label to yellow end



Step 3: Remove bundled fiber from winding jig




Step 4: Bundle each fiber end keeping off recoating area by spiral tubes



Step 5: Prepare separated area and put products into case


Confidential FOV 's property, do not take out without FOV BOM's approval

#### 




Keep same direction of all sponge sheets (cut corner must be located in the upper right side of the compartment)

Step 6: Put 60 products in case and cover by sponge.




Step 7: Cover tray and paste label

### 13.1.2.7 Inner packing for patt 7




Step 1: Rewind to the winding jig from red side

CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 37/54			




Step 2: Remove bundled fiber from winding jig




Step 3: Bundle each fiber end keeping off recoating area by spiral tubes


(Detail of transparent tape)




#### 



Step 4: Attach transparent tape to fiber end and attach serial label on it. (Transparent tape and serial label can be attached before bundling each fiber end)




### Rotation method of winded fiber



Label of 5th product will direct to corner A same with 1st product.

Step 5: Prepare separated area and put products into case with right direction.

#### 




Keep same direction of all sponge sheets (cut corner must be located in the upper right side of the compartment)

# (Put sponge cover)



Step 6: Put 60 products in case and cover by sponge.




Step 7: Cover tray and paste label

# 13.1.2.8 Inner packing for patt 8 Winding jig


Step 1: Rewind to the winding jig from red side

CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 40/54			




Step 2: Attach serial label to red end

Attach in red side



Step 3: Remove bundled fiber from winding jig



Step 4: Bundle each fiber end keeping off recoating area by spiral tubes





Step 5: Put the individual fiber bundle into zipper bag and close the zipper.

Confidential FOV 's property, do not take out without FOV BOM's approval


CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 41/54			

13.1.2.9 Inner packing for patt 9





Step 2: Attach serial label to red end



Remove bundled fiber from winding jig

Confidential FOV 's property, do not take out without FOV BOM's approval


CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 42/54			

Step 4: Bundle each fiber end keeping off recoating area by spiral tubes




Step 5: Put the individual fiber bundle into zipper bag and close the zipper


# 13.1.2.10 Inner packing for patt 10



Step 1: Rewind to the winding jig from red side




Step 2: Attach serial label to red end



Confidential FOV 's property, do not take out without FOV BOM's approval

CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 43/54			

Step 3: Remove bundled fiber from winding jig



Step 4: Bundle each fiber end keeping off recoating area by spiral tubes



Step 5: Put the individual fiber bundle into zipper bag and close the zipper

# 13.2. Process condition

Item	Condition
Amnaguanaa	Visual
Appearance	Microscope (To confirm NC)
Langth	Template
Length	Ruler (To confirm NC)
Madrina	Template
Marking	Ruler (To confirm NC)
Packing quantity and serial No. order	Program and Jig
Fiber protrusion length (if required)	Template/Ruler
Contamination/hair	Ionizer Fan


CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 44/54			

#### 14 Final Packing


# 14.1. Process specification

Item	Specification
Appearance	No damage for inner package, inner carton box, outer carton box
Quantity of block in the inner carton box	Max 1 blocks
Quantity of the inner carton box in an outer carton box	Refer to relative product structure
Storage condition	Thermal (0 – 30°C) (Refer 4-PR-014 Table 1 (Final Packing area & Storage area of Product which required storage conditions))


14.1.1 Outer packing specification patt A



Step 1: Put product case with small serial No. at bottom and latest serial No at top. Max 4 cases



#### 



For example (Packing form chip, Bubble wrap, Trikon, empty inner carton box)

No move the block in an outer carton box.

Can use Empty Box to fill up the outer carton box when there is not enough products to pack fill up for 6 inner carton boxes

#### 2. Attach outer box label



Contents of box label


- \*P/O No
- \*Product name
- \*Quantity
- \*Shipping date
- \*Box number (current and total number)
- \*Order number

(informed by ODD's planner)

Step 2: Put inner boxes and empty box into outer box


#### 14.1.2 Outer packing specification patt B





Reverse the direction of zipper of plastic bags after per 10 pcs

Step 1: Put the individual zipper bags into inner carton box and insert bubble sheet after per 10 pcs



24mm (Tze-251)

Sample of package label

Step 2: Attach the label to the inner carton box.


#### Contents of inner carton box label

- -Serial No. (first and last serial in the case)
- -Part number and Version
- -Quantity (pcs)
- -CW (center value of spec)
- -Country of origin
- -Box No.
- \*Refer to outer box label

Note: Fill up an interspace with cushioning material. For example:

- + Packing form chip, Bubble wrap, Trikon, empty inner carton box.
- + No move the block in an outer carton box.
- + Can use Empty Box to fill up the outer carton box when there is not nough product to pack fill up for 6 inner carton boxes. In that case, please indicate "Empty" on the box.


CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 46/54			




10 inner carton boxes are arranged in 2 rows.
Fill up an interspace with cushioning material.

Step 3: Put 10 inner carton boxes into an outer carton box and attach outer box label


# 14.1.3. Outer packing specification patt C



Step 1: Wrap the inner package in the bubble sheet (maximum 5 packages).



Step 2: Put 1 block into an inner carton box



Step 3: Put inner carton boxes into an outer carton box (maximum 6 inner carton boxes) and attach outer box label

<u>Note</u>: Need ODD's approval before changing carton box size or maximum capacity per box even if it meets specification.

#### Noted for Box label format


The formats are separated depending on packing type and the order types VMI P/O or Other. VMI P/O is indicated on PURCHASE ORDER SHEET. The contents are shown in Table 14-3. Box label formats and PURCHASE ORDER SHEET example are shown in Fig.1, Fig.2.

Table 14-3: Box label contents


Packing type	A, B, E, F, H, J, <b>K</b>	C, 1	D, G
Label format	Standard	VMI P/O	Other
Customer order No.	0	0	0
P/O No./Lot.No.	0	X	X
Product name	0	0	0
Quantity	0	0	0
Shipping date	0	0	0
Box number	*1	0	*1
VMI P/O identification	X	0	X
Vendor Name	X	0	0
Purchasing PO#	X	o *2	o *2
II-VI Part No.	X	o *2	o *2
Version	X	0	0
Batch/Lot Number	X	o *2	o *2


o: to be displayed, x: not to be displayed, \*1 may be displayed, \*2 to be displayed with Code 39 barcode

# CAVITY-FG PRODUCT OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 48/54



#### (a) Format for Standard





(b) Format for VMI P/O

(c) Format for Other

Fig.1 Box label formats

	VMI P/O	Other
①Box number	Current number should be consecutive	Current number may be consecutive
(current number /	number within each P/O. Total quantity	number and Total quantity may be
total quantity)	should be counted as each P/O.	counted in particular shipping date.
②VMI P/O	The words "VMI" should be displayed.	The words "VMI" must not be
identification		displayed.

CAVITY-FG PRODUCT			
OPERATION PROCEDURE: 4-OP-378 Version: 67 Page: 49/54			





Fig.2 PURCHASE ORDER SHEET example with VMI P/O

- \*3 FOV should not change label format without ODD's approval.
- \*4 Order No is Batch/Lot Number.
- \*5 Product name/Type contains customer information.



\*6 There are the words "VMI" at the end of Remarks column only VMI P/O.



#### 14.2 Process condition

Item	Condition
Packing quantity	Program
Appearance	Visual
Storge condition	Thermal recorder

# 15. Test report & Shipping 67



- Shipping quantity and product name must be confirmed correct with P/O from Customer
- Attach label outside carton box to indicate: Specification of product type, Specification Number and serial No.
- Update Data (test report and E-data) to FTP server IP: 10.16.248.14
- Shipping date of deliverable data:
  - + Uploading deliverable data by 11AM of 2 days before shipping day in Vietnam time.
  - + If you cannot upload TR in time, inform QA in ODD by 11AM of 2 days before shipping day.
  - + Counting number of days is working day in Vietnam except for Saturday and Sunday.
  - + After 11AM of 2days before shipping day, DON'T replace TR on your server before informing ODD.
- In case storage period after the last measurement date over 1 year, the product has to be re-measured before shipping.
- FOV must inform to Fujikura before re-measure the stock products.
- After measurement Fujikura will review the results and judge they can be shipped or not.
- The measurement value in the test report should be the result of re-measurement.

CAVITY-FG PRODUCT				
OPERATION PROCEDURE: 4-OP-378	Version: 67	Page: 50/54		

# **Note for test report:**

- 1. Optical measurement data should be described to two decimal places
- 2. For the items as shown below, the specified value needs to be written in Spec column
  - Center Wavelength
  - Reflectivity
  - FWHM
  - SLSR
  - Fiber length in / Fiber (pigtail A)
  - Recoat length
  - Fiber length out / Fiber (pigtail B)
- 3. Detailed requirements for each type, refer to Spec No. AOP82-4001-27-12

CAVITY-FG PRODUCT					
OPERATION PROCEDURE: 4-OP-378	Version: 67	Page: 51/54			

# **REVISION HISTORY**

REVISION HISTORY						
Date	PIC	Ver	Old contents	Description New contents	Reason of change	Change requester
			II. Application Table II.1 Products general information N/A	II. Application Table II.1 Products general information Add new products XEV, XFV		
	VietTA		III. Reference Documents:  1	III. Reference Documents:  1	Customer update Specifications Version	TrungDN
			Table 4.1.1 Cutting length of Cavity-FG N/A	Table 4.1.1 Cutting length of Cavity-FG Add new products XEV, XFV		
09-Sep-2024		67	12. Optical Measurement N/A	12. Optical Measurement Add new products XEV, XFV		
			II. Application Table II.2 Processes for Cavity-FG Item 15. Shipping	II. Application Table II.2 Processes for Cavity-FG Item 15. Test report & Shipping	Correction (as internal review from audit no QLA2404)	
			Table 13.1.1.2 Length of Cavity product - Type name: HAV, HBV, HCV, HDV, HEV, HFV, HGV, HHV, HJV, HKV: Refer to figure 13.1.1.10	Table 13.1.1.2 Length of Cavity product - Type name: HAV, HBV, HCV, HDV, HEV, HFV, HGV, HHV, HJV, HKV: Refer to figure 13.1.1.12	- Correction	
	ThuyNT D		- Remain of type name: Refer to figure 13.1.1.9	- Remain of type name: Refer to figure 13.1.1.11	- Correction	DucNTM
	D		- N/A	- Add new products XEV, XFV	- Customer update Specifications Version add new product code.	
			VI. Content: 15. Shipping	VI. Content: 15. Test report & Shipping	Correction (as internal review from audit no QLA2404)	
14-Aug-2024	VietTA	66	Material preparation     Fiber Optical Rewinding	1.Incoming Inspection 2. Fiber Rewinding	Action for finding internal audit 8-Aug- 2024	TrungDN
1-Aug-2024	VietTA ThuyNT D	65	III. Reference Documents:  1	III. Reference Documents:  1	Customer update Specifications Version	TrungDN
			III. Reference document. 2. Working direction PTE82-59-24-2003(01) PTE82-59-24-2007 PTE82-59-23-2010 PTE82-59-23-2023	III. Reference document 2. Working direction Remove	The content of WD was updated in new specifications version	
			Table 4.1.1 Cutting length of Cavity-FG. Fiber length of KBV, KCV, KXV, KYV	Table 4.1.1 Cutting length of Cavity-FG. Change Fiber length of KBV, KCV, KXV, KYV	Update follow new	
			5.1 Process specification Stripping length: - Fiber 80um: ≤ 5mm	5.1 Process specification Stripping length: - Fiber 80um: < 4.5mm	specifications version	

CAVITY-FG PRODUCT					
OPERATION PROCEDURE: 4-OP-378	Version: 67	Page: 52/54			

	т —			T	1	1
			6. Exposing and Thermal aging Excimer Laser Energy Manufacturing: 120mJ, mode EGY-N	6. Exposing and Thermal aging Excimer Laser Energy Manufacturing: 120mJ, mode EGY-N or EGY-P	Update follow CO :9-PR-0014- 9-FO-0001-4- RC-0127	
			7.Thermal Aging (hot air) process N/A	7.Thermal Aging (hot air) process Stripping movement Pre-Heating Velocity	Update to match with control process	
			11.1.3. Apply for all products belong RV3 Deformation and discoloration + Defect Size/ Condition Length of deformation or discoloration of fiber coating is greater than 0.25mm + N/A	11.1.3. Apply for all products belong RV3 Deformation and discoloration + Defect Size/ Condition At buffer/glass interface + Add Fig. 11.1.3.3&11.1.3.4	Update follow new specifications	
			Table 13.1.1.2 Length of Cavity product Fiber length of KBV, KCV, KXV, KYV + L2: 1245 ± 25 mm	Table 13.1.1.2 Length of Cavity product Fiber length of KBV, KCV, KXV, KYV + L2: 845 ± 25 mm	version.	
			13.1.2.7 Inner packing for patt 7: Products have scotch tape at yellow port and red port.	13.1.2.7 Inner packing for patt 7: Delete scotch tape at yellow port.		
			13.1.2.9 Inner packing for patt 9: Have 2 format label: a. For UAV, UBV; TAV, TBV products b. For other products	13.1.2.9 Inner packing for patt 9: Update format label for patt 9, delete format label for: + UAV, UBV products + Other product	Follow AOP82-4001- 27-08(24)	
			13.1.2.10 Inner packing for patt 10: N/A	13.1.2.10 Inner packing for patt 10: Add method packing for patt 10.		
			14.1. Process specification: N/A	14.1. Process specification: Add storage condition Thermal (0 – 30°C)  14.2 Process condition: Add storage condition:	-Add storage conditional from	
			14.2 Process condition: N/A	thermal recorder.	specification	
			15 Shipping + N/A + Update Data (test report and Shipping data) to FTP server	15 Shipping + Add Re-measurement for stock products. + Update Data (test report and E-data) to FTP server (Change "Shipping data" to "E-data")	Follow AOP82- 4001-27-07(09)	
			III.Reference document. 2. Working direction - PTE82-59-21-2005	III.Reference document. 2. Working direction - Remove	FOV didn't use resin 950Y200	
4-Jun-2024	NguyenV T	64	IV. Content 4. Fiber cutting Table 4.1.1 Cutting length of Cavity-FG. L1 = 120 ± 50 5. Fiber Stripping 5.1 Process specification - Stripping position: N/A	IV. Content 4. Fiber cutting Table 4.1.1 Cutting length of Cavity-FG. Remove L1 5. Fiber Stripping 5.1 Process specification - Stripping position: Add note	Following 9-PR- 0014-9-FO- 0001-4-RC-0105	ChienPH
			III. Reference Documents: 2. Working Direction No.: N/A	III. Reference Documents: 2. Working Direction No.: Add WD: PTE82-59-24-2007		
26-Mar-2024	VietTA	63	7.Thermal Aging (hot air) process N/A	7.Thermal Aging (hot air) process - Frequency: 3pcs/OP/day	Add WD: PTE82-59-24- 2007	TrungDN
			Table 11.1.3.1 Defect Size and Frequency Criteria within Recoat Zone (RV3) N/A	Table 11.1.3.1 Defect Size and Frequency Criteria within Recoat Zone (RV3) + Defect Type: Deformation and discoloration	2007	
8-Mar-2024	VietTA	62	II. Application   Type name   RLS (mm)   HCV   > 21   HDV   > 21   HEV   > 21   HFV   > 21   HHV   > 21   HJV   > 21   HJV   > 21   HKV   > 21   HKV	II. Application	Removed WD: PTE82-59-23- 2029	TrungDN
			2.Working Direction No.:  PTE82-59-23-2029  5. Fiber stripping Stripping length: - Fiber 80um: 20~ 24 mm 6. Exposing and Thermal aging	2.Working Direction No.:  Remove PTE82-59-23-2029  5. Fiber stripping Stripping length: - Fiber 80um: ≤ 5mm  6. Exposing and Thermal aging		

CAVITY-FG PRODUCT				
OPERATION PROCEDURE: 4-OP-378	Version: 67	Page: 53/54		

			- Item Specification	N/A	1	
			FBG position FBG position is <4.5mm	IN/A		
			(80um 980PM from red port side stripping edge.			
			-Add Fg 6.1.4: FBG position(80um)			
			Marking and proof test	Marking and proof test	-	
			Recoating length:	Recoating length:		
			+ > 21mm (D06: Refer to table II. 1, column RLS	+ > 5mm (D06: Refer to table II. 1, column RLS)		
			III. Reference Documents:	III. Reference Documents:		
			2.Working Direction No.:	2. Working Direction No.:	Add new WD:	
			N/A 15 Shipping	PTE82-59-24-2003(01) 15 Shipping	PTE82-59-24- 2003(01)	
			N/A	Add content of PTE82-59-24-2003(01)		
			12. Optical Measurement 12.2 Process condition	12. Optical Measurement 12.2 Process condition	Update to match with control	
			N/A	+ Add thermometer position	process	
			III.2. Working Direction No.	III.2. Working Direction No.	Customer issue WD for Fiber	
			Not have item 4, 5	Add item 4, 5	Inspection and	
			With William Company	W 10 Vi V V V V V V V V V V V V V V V V V V	Packing process	
	QAE		VI.13. Visual Inspection and Packing NA	VI.13. Visual Inspection and Packing Revise Fig 13.1.1.1 and 13.1.1.2		
16-Jan-2024	VanPNT	61	VI.13. Visual Inspection and Packing Table 13.1.1.1	VI.13. Visual Inspection and Packing Table 13.1.1.1	Follow PTE82-	DucTNM
	(10896)		Delamination with Length in longitudinal	Delamination not easy to find by naked eyes - Not	59-23-2023	
			direction >1mm or with damage – Not accepted	accepted		
			VI.13. Visual Inspection and Packing	VI.13. Visual Inspection and Packing	Follow PTE82-	
			13.1.2.9. Step 2 NA	13.1.2.9. Step 2 Add illustration of new label format for 3SP products	59-23-2010	
			II. Application	II. Application		TrungDN
			Type name RLS (mm) HCV > 5	Type name RLS (mm) HCV > 21		
			HDV > 5 HEV > 5	HDV > 21 HEV > 21		
			HEV   > 5   HFV   > 5	HEV > 21 HFV > 21		
			HHV   > 5   HJV   > 5	HHV > 21 HJV > 21	Follow PTE82-	
			HKV >5	HKV > 21	59-23-2029	
			III. Reference Documents:	III. Reference Documents:		
			2.Working Direction No.:	2. Working Direction No.:		
			N/A	+ Add PTE82-59-23-2029		
			W DOMG	V. ROHS material requirement & Traceability		
			V. ROHS requirement: 1. Material list	control1.  1.ROHS material requirement		
				2.Traceability control1.		
					Follow new concept 0-Pr-	
	VietTA		VI. Content:	VI. Content:	001-5-WI-0749	
20-Dec-2023	10811	60	1.3. Material list 1.4. Checking items.	<ul><li>Cancel 1.3 Material list.</li><li>Cancel 1.4 Checking items.</li></ul>		
			1.4. Checking items.	Cancer 1.4 Checking Items.		
			5. Fiber stripping	2 500		
			Stripping length:	5. Fiber stripping Stripping length:		
			- Fiber 80um: ≤ 5mm 6. Exposing and Thermal aging	- Fiber 80um: 20~ 24 mm 6. Exposing and Thermal aging		
			N/A	- Item Specification	Follow PTE82-	
				FBG position FBG position is <4.5mm (80um 980PM from red port side stripping edge.	59-23-2029	
				-Add Fg 6.1.4: : FBG position(80um		
			8. Recoating process	8. Recoating process	Products have diameter D04 is	
			- (D04) <= 260um or >= 300um	- (D04) <= 260um or >= 300um - Cancel picture D04	no longer	
			Marking and proof test	9. Marking and proof test	available Follow PTE82-	
			Recoating length:	Recoating length:	59-23-2029	

CAVITY-FG PRODUCT				
OPERATION PROCEDURE: 4-OP-378	Version: 67	Page: 54/54		

			+ > 5mm (D06: Refer to table II. 1, column RLS)	+>21mm (D06: Refer to table II. 1, column RLS)		
	PRE3 HuyDM 10893		General Information table: - N/A Exposing process condition - N/A	General Information table: - Spectrum type Exposing process condition - Spectrum type	Correction (as internal review for RCV issue)	TrungDN
27-July-2023	VietTA 10811	59	III. Reference Documents  No Specification  1 AOP82-4001-27-04(15)  2 AOP82-4001-27-09(18)  5 AOP81-2122-27-01(16)  6 AOP82-4001-27-13(02)  7 AOP82-4001-27-14(02)	III. Reference Documents  No Specification  1 AOP82-4001-27-04(16)  2 AOP82-4001-27-09(19)  5 AOP81-2122-27-01(17)  6 AOP82-4001-27-13(03)  7 AOP82-4001-27-14(03)	Customer update Specifications Version	HuigoN